


WORK AREA JIB CRANES

- * Thru 1000# Capacity
- * Thru 16 Foot Boom radius
- * Thru 14 Foot HUB (Height Under Boom -BMJ Jibs)
- * "Hoist-Trolley" Included With Jibs
- * Not Included: Bolts For Mounting Wall Bracket Jib Crane to Structure
Anchor Bolts or Anchor Bolt Cages For Base Mounted Jibs
Electrical or Air Festooning (See Options)

* Part Number Explanation:

100 - WBJ - 10

- Jib Span (Boom Radius)
- Type Of Jib Crane
WBJ = Wall Bracket Jib
- Capacity (In Pounds)




WALL BRACKET JIB

* Part Number Explanation:

100 - BMJ - 10 - 10

- Jib Span (Boom Radius)
- HUB (Height Under Boom)
- Type Of Jib Crane
BMJ = Base Mounted Jib
- Capacity (In Pounds)



BASE MOUNTED JIB